



**Blinds CC**

*Perfect Sun Control*

### 35mm Aluminium Venetian Blind Installation Instruction

The brackets provided are universal, and can be top or face fixed through the pre-formed holes in the brackets. Each bracket must be installed with two suitable masonry plugs and screws.

#### Step 1

The top of the reveal must be a minimum of 40mm deep in order to accommodate the blind, and must be free from any obstruction. Place the blind in the area in which it is to be fitted and mark the position of each of the ladder lace which support the slats. Position and fit each bracket approximately 40mm to the left or right of the marked positions, ensuring that the bracket will not obstruct any moving parts of the blind. Fit one bracket per ladder lace, and make sure that they are all straight and in line. Brackets should be fitted at a sufficient distance from the window so that when the blind is installed it will clear window handles and other obstructions.

#### Step 2

With the latch of the bracket in an open position, locate the front inside lip of the headrail onto the two front lips of the bracket. After pushing the headrail firmly into the brackets, close the latch of the brackets in the opposite direction, which now will ensure that the latch is now flush with the front of the headrail. Check that the blind is firmly retained in the bracket before operating the blind.

#### Face Fixing

All the above needs to be observed, except that the blind has now been installed on the outside of the window opening.

#### Operating Instructions

##### Raising:

With slats fully open, draw the cords vertically downwards until the desired height is reached, then incline cords slightly outwards to lock in position.

##### Lowering:

Pull cords towards centre of the blind and release gently through the hand until drop required is reached. Lock cords as in raising.

##### Tilting:

Rotate the clear plastic wand to incline the slats to whatever angle is desired.

NEVER RAISE THE BLIND WHEN SLATS ARE IN A CLOSED POSITION

**Contact Details:** Tel: 031 579 2670  
Fax: 031 579 2680  
Email: [orders@ventolite.co.za](mailto:orders@ventolite.co.za)  
Web: [www.ventolite.co.za](http://www.ventolite.co.za)

**Address:** Ventolite Blinds CC  
Unit 19 Springriver Park  
48 Ebonyfield Avenue  
Springfield Park  
Durban